



## **Acoustic Wall Panels**


## You need:

Glue and glue gun Spirit level Pencil Cordless screwdriver Screws The acoustic panels are glued or screwed to the wall to the wall. For each panel, at least 15 screws at a maximum distance of 60 cm are required for each panel.

Choose the direction in which you want to lay your acoustic panels. After measuring, you can the panels can be shortened at the back with a fine-toothed jigsaw or hand saw.







When the acoustic panels are fixed to the ceiling, screws must always be used.



